

CIS 501 Computer Architecture


Unit 5: Virtual Memory

Slides originally developed by Amir Roth with contributions by Milo Martin at University of Pennsylvania with sources that included University of Wisconsin slides by Mark Hill, Guri Sohi, Jim Smith, and David Wood.

Readings

- P+H
 - Virtual Memory: C.4, C.5 starting with page C-53 (Opteron), C.6


This Unit: Virtual Memory



- The operating system (OS)
 - A super-application
 - Hardware support for an OS
- Virtual memory
 - Page tables and address translation
 - TLBs and memory hierarchy issues


A Computer System: Hardware

- CPUs and memories
 - Connected by memory bus
- **I/O peripherals**: storage, input, display, network, ...
 - With separate or built-in DMA
 - Connected by **system bus** (which is connected to memory bus)



A Computer System: + App Software

- **Application software:** computer must do something




CIS 501 (Martin/Roth): Virtual Memory

5

A Computer System: + OS

- **Operating System (OS):** virtualizes hardware for apps
 - **Abstraction:** provides **services** (e.g., threads, files, etc.)
 - + Simplifies app programming model, raw hardware is nasty
 - **Isolation:** gives each app illusion of private CPU, memory, I/O
 - + Simplifies app programming model
 - + Increases hardware resource utilization



CIS 501 (Martin/Roth): Virtual Memory

6

Operating System (OS) and User Apps

- Sane system development requires a split
 - Hardware itself facilitates/enforces this split
- **Operating System (OS):** a super-privileged process
 - Manages hardware resource allocation/revocation for all processes
 - Has direct access to resource allocation features
 - Aware of many nasty hardware details
 - Aware of other processes
 - Talks directly to input/output devices (device driver software)
- **User-level apps:** ignorance is bliss
 - Unaware of most nasty hardware details
 - Unaware of other apps (and OS)
 - Explicitly denied access to resource allocation features

CIS 501 (Martin/Roth): Virtual Memory

7

System Calls

- Controlled transfers to/from OS
- **System Call:** a user-level app "function call" to OS
 - Leave description of what you want done in registers
 - SYSCALL instruction (also called TRAP or INT)
 - Can't allow user-level apps to invoke arbitrary OS code
 - Restricted set of legal OS addresses to jump to (**trap vector**)
 - Processor jumps to OS using trap vector
 - Sets privileged mode
 - OS performs operation
 - OS does a "return from system call"
 - Unsets privileged mode

CIS 501 (Martin/Roth): Virtual Memory

8

Interrupts

- **Exceptions:** synchronous, generated by running app
 - E.g., illegal insn, divide by zero, etc.
- **Interrupts:** asynchronous events generated externally
 - E.g., timer, I/O request/reply, etc.
- **“Interrupt” handling:** same mechanism for both
 - “Interrupts” are on-chip signals/bits
 - Either internal (e.g., timer, exceptions) or from I/O devices
 - Processor continuously monitors interrupt status, when one is high...
 - Hardware jumps to some preset address in OS code (interrupt vector)
 - Like an asynchronous, non-programmatic SYSCALL
- **Timer:** programmable on-chip interrupt
 - Initialize with some number of micro-seconds
 - Timer counts down and interrupts when reaches 0


Virtualizing Processors

- How do multiple apps (and OS) share the processors?
 - **Goal: applications think there are an infinite # of processors**
- Solution: time-share the resource
 - Trigger a **context switch** at a regular interval ($\sim 1\text{ms}$)
 - **Pre-emptive:** app doesn't yield CPU, OS forcibly takes it
 - + Stops greedy apps from starving others
 - **Architected state:** PC, registers
 - Save and restore them on context switches
 - Memory state?
 - **Non-architected state:** caches, predictor tables, etc.
 - Ignore or flush
- Operating responsible to handle context switching
 - Hardware support is just a timer interrupt

Virtualizing Main Memory

- How do multiple apps (and the OS) share main memory?
 - **Goal: each application thinks it has infinite memory**
- One app may want more memory than is in the system
 - App's insn/data footprint may be larger than main memory
 - **Requires main memory to act like a cache**
 - With disk as next level in memory hierarchy (slow)
 - Write-back, write-allocate, large blocks or “pages”
 - No notion of “program not fitting” in registers or caches (why?)
- Solution:
 - Part #1: treat memory as a “cache”
 - Store the overflowed blocks in “swap” space on disk
 - Part #2: add a level of indirection (address translation)


Virtual Memory (VM)



- Programs use **virtual addresses (VA)**
 - $0 \dots 2^N - 1$
 - VA size also referred to as machine size
 - E.g., 32-bit (embedded) or 64-bit (server)
- Memory uses **physical addresses (PA)**
 - $0 \dots 2^M - 1$ (typically $M < N$, especially if $N=64$)
 - 2^M is most physical memory machine supports
- VA \rightarrow PA at **page** granularity (VP \rightarrow PP)
 - By “system”
 - Mapping need not preserve contiguity
 - VP need not be mapped to any PP
 - Unmapped VPs live on disk (swap)

Virtual Memory (VM)

- **Virtual Memory (VM):**
 - Level of indirection
 - Application generated addresses are **virtual addresses (VAs)**
 - Each process **thinks** it has its own 2^N bytes of address space
 - Memory accessed using **physical addresses (PAs)**
 - VAs translated to PAs at some coarse granularity
 - OS controls VA to PA mapping for itself and all other processes
 - Logically: translation performed before every insn fetch, load, store
 - Physically: hardware acceleration removes translation overhead



CIS 501 (Martin/Roth): Virtual Memory

13

VM is an Old Idea: Older than Caches

- Original motivation: **single-program compatibility**
 - IBM System 370: a family of computers with one software suite
 - + Same program could run on machines with different memory sizes
 - Prior, programmers explicitly accounted for memory size
- But also: **full-associativity + software replacement**
 - Memory t_{miss} is high: extremely important to reduce $\%_{miss}$


Parameter	I\$/D\$	L2	Main Memory
t_{hit}	2ns	10ns	30ns
t_{miss}	10ns	30ns	10ms (10M ns)
Capacity	8-64KB	128KB-2MB	64MB-64GB
Block size	16-32B	32-256B	4+KB
Assoc./Repl.	1-4, NMRU	4-16, NMRU	Full, "working set"

CIS 501 (Martin/Roth): Virtual Memory

14

Uses of Virtual Memory

- More recently: **isolation** and **multi-programming**
 - Each app thinks it has 2^N B of memory, its stack starts 0xFFFFFFFF,...
 - Apps prevented from reading/writing each other's memory
 - Can't even address the other program's memory!
- **Protection**
 - Each page with a read/write/execute permission set by OS
 - Enforced by hardware
- **Inter-process communication.**
 - Map same physical pages into multiple virtual address spaces
 - Or share files via the UNIX `mmap()` call




CIS 501 (Martin/Roth): Virtual Memory

15

Virtual Memory: The Basics

- Programs use **virtual addresses (VA)**
 - VA size (N) aka machine size (e.g., Core 2 Duo: 48-bit)
- Memory uses **physical addresses (PA)**
 - PA size (M) typically $M < N$, especially if $N=64$
 - 2^M is most physical memory machine supports
- VA \rightarrow PA at **page** granularity (VP \rightarrow PP)
 - Mapping need not preserve contiguity
 - VP need not be mapped to any PP
 - Unmapped VPs live on disk (swap) or nowhere (if not yet touched)



CIS 501 (Martin/Roth): Virtual Memory

16


Multi-Level Page Table (PT)

- 20-bit VPN
 - Upper 10 bits index 1st-level table
 - Lower 10 bits index 2nd-level table

```

struct {
    int ppn;
    int is_valid, is_dirty, is_swapped;
} PTE;
struct { struct PTE ptes[1024]; } L2PT;
struct L2PT *page_table[1024];


int translate(int vpn) {
    index1 = (vpn >> 10); // upper 10 bits
    index2 = (vpn & 0x3ff); // lower 10 bits
    struct L2PT *l2pt = page_table[index1];
    if (l2pt != NULL &&
        l2pt->ptes[index2].is_valid)
        return l2pt->ptes[index2].ppn;
}
    
```



21

Multi-Level Page Table (PT)

- Have we saved any space?
 - Isn't total size of 2nd level tables same as single-level table (i.e., 4MB)?
 - Yes, but...
- Large virtual address regions unused
 - Corresponding 2nd-level tables need not exist
 - Corresponding 1st-level pointers are null
- Example: 2MB code, 64KB stack, 16MB heap
 - Each 2nd-level table maps 4MB of virtual addresses
 - 1 for code, 1 for stack, 4 for heap, (+1 1st-level)
 - 7 total pages = 28KB (much less than 4MB)



22

CIS 501 (Martin/Roth): Virtual Memory

Page-Level Protection

- **Page-level protection**
 - Piggy-back page-table mechanism
 - Map VPN to PPN + Read/Write/Execute permission bits
 - Attempt to execute data, to write read-only data?
 - Exception → OS terminates program
 - Useful (for OS itself actually)

```

struct {
    int ppn;
    int is_valid, is_dirty, is_swapped, permissions;
} PTE;
struct PTE page_table[NUM_VIRTUAL_PAGES];

int translate(int vpn, int action) {
    if (page_table[vpn].is_valid &&
        !(page_table[vpn].permissions & action)) kill;
    ...
}
    
```

23


Address Translation Mechanics II

- Conceptually
 - Translate VA to PA before every cache access
 - Walk the page table before every load/store/insn-fetch
 - Would be terribly inefficient (even in hardware)
- In reality
 - **Translation Lookaside Buffer (TLB)**: cache translations
 - Only walk page table on TLB miss
- Hardware truisms
 - Functionality problem? Add indirection (e.g., VM)
 - Performance problem? Add cache (e.g., TLB)


CIS 501 (Martin/Roth): Virtual Memory

24


Translation Lookaside Buffer




Serial TLB & Cache Access



Parallel TLB & Cache Access



Parallel TLB & Cache Access



TLB Organization

- **Like caches:** TLBs also have ABCs
 - Capacity
 - Associativity (At least 4-way associative, fully-associative common)
 - What does it mean for a TLB to have a block size of two?
 - Two consecutive VPs share a single tag
 - **Like caches:** there can be L2 TLBs
- Example: AMD Opteron
 - 32-entry fully-assoc. TLBs, 512-entry 4-way L2 TLB (insn & data)
 - 4KB pages, 48-bit virtual addresses, four-level page table
- **Rule of thumb:** TLB should “cover” L2 contents
 - In other words: $(\#PTEs \text{ in TLB}) * \text{page size} \geq \text{L2 size}$
 - Why? Consider relative miss latency in each...

CIS 501 (Martin/Roth): Virtual Memory

29

Page Faults

- **Page fault:** PTE not in TLB or page table
 - → page not in memory
 - Or no valid mapping → segmentation fault
 - Starts out as a TLB miss, detected by OS/hardware handler
- **OS software routine:**
 - Choose a physical page to replace
 - **“Working set”:** refined LRU, tracks active page usage
 - If dirty, write to disk
 - Read missing page from disk
 - Takes so long (~10ms), OS schedules another task
 - Requires yet another data structure: **frame map** (why?)
 - Treat like a normal TLB miss from here

CIS 501 (Martin/Roth): Virtual Memory

31

TLB Misses

- **TLB miss:** translation not in TLB, but in page table
 - Two ways to “fill” it, both relatively fast
- **Software-managed TLB:** e.g., Alpha, MIPS, ARM
 - Short (~10 insns) OS routine walks page table, updates TLB
 - + Keeps page table format flexible
 - Latency: one or two memory accesses + OS call (pipeline flush)
- **Hardware-managed TLB:** e.g., x86
 - Page table root in hardware register, hardware “walks” table
 - + Latency: saves cost of OS call (avoids pipeline flush)
 - Page table format is hard-coded
- Trend is towards hardware TLB miss handler

CIS 501 (Martin/Roth): Virtual Memory

30

Summary

- OS virtualizes memory and I/O devices
- Virtual memory
 - “infinite” memory, isolation, protection, inter-process communication
 - Page tables
 - Translation buffers
 - Parallel vs serial access, interaction with caching
 - Page faults

CIS 501 (Martin/Roth): Virtual Memory

32